


Installation Instructions



Micro Cement Kit



Please ensure all tradesman working on or around the installation have consulted these instructions and understand how to maintain the waterproofing integrity.

Guarantee

If installed correctly by a competent person and used for normal wetroom applications the Maxxus (and membrane if supplied by us) have a life-of-tile guarantee (if grout lines are maintained). No guarantee is offered where this is not the case.

Installation Overview

These instructions assume the wetroom has been appropriately designed and all plumbing and electrical work is to building regulations. These instructions will cover the most typical level floor installations on suspended timber or solid concrete floors. For raised floor areas the instructions can be applied where appropriate.


The Maxxus is a load bearing deck which can sustain a load of 470kgs over 400mm joist centres without deflection and as such require no under boarding

Installation on Timber Floors

If setting the deck into an existing timber floor first remove the floorboards to expose the joists in the area where the deck will be fitted. Inspect the integrity of the existing joists and if in doubt remedial action should be taken to ensure the floor is strong and stable. The Maxxus deck can be laid straight over the existing joists without under boarding, however if the joist centres are over 400mm install additional noggins for support. All edges of the deck must also be supported with noggins.

The waste connection must now be considered.

Lay the deck into position and connect the waste.
Pilot drill the deck and screw down to the joists securely using wood screws.
Check to make sure there is no movement and the deck is level.



Installation on Concrete Floors

Installing inset into concrete,
The area beneath the deck must be cut and chiseled out to accommodate the deck, drain and waste pipe.
For final fitting fully bed the deck down on tile adhesive ensuring the deck is level then allow to fully dry.
Pilot drill the deck and screw down.
Ensure there is no movement and the deck is level.

Installing on Top of Concrete,
A cavity and channel must be chiseled out to accommodate the drain and waste pipe.
If the floor is not level the deck may be bedded down on tile adhesive, adjusted to level then allowed to dry.
Pilot and screw the deck down.
Ensure there is no movement and the deck is level.

Micro Cement Grid Installation Instructions



Do not remove the protective film until the micro cement has been laid

1. Install the drain into the tray/floor and tank as required.
2. Place the grid into the top of the drain (check the clamping ring has been removed from the drain top section).
3. The grid has two sides, an infill side and a standard finish side.
4. If using the infill side lay the micro cement into this at the same time as the rest of the floor.
5. If using the standard finish side ignore the infill.
6. Lay micro cement.
7. Remove protective film from grid top.
8. Remove any excess residue using a non abrasive cloth and hot soapy water.
9. Flip grid over to standard finish grid if required.

Components Required

Disregard any other parts that may have been included in the drain box

